Classic

School Timer ST 1000

User Manual Book

FEATURE:

Ø   Bright LCD display for clear text messages.

Ø   User friendly by keypad.

Ø   24 Alarm for each weekday.

Ø   User define alarm duration.

Ø   Password protection facility for security.

Ø   Easy installation with built-in Bell socket.

Ø   More than one Electric bell can be connected.

Ø   Built-in battery backup to keep save Time and Alarms in power failure.

Ø   Reset button in case of forget password.

Press any key for entering in password mode.

Enter 5 digits password and press D for Entering in Setting Manu.

(For Example: 12345)   [Default Password: 12345]

SETTING TIME:

Press 1 to Enter in Setting time Manu.

Only four buttons are used.

A: Return

B: Increment (+)

C: Decrement (-)

D: Next & Save

Ø   Press B and C for Increment and Decrement respectively.

Ø   Press D for next digit and save.

Ø   Press A for Return.

SETTING ALARMS:

Press 2 to Enter in Setting alarm Manu.

In setting alarm Manu three mode of days are available as shown.

Monday-Thursday

Press 1 to Enter in this mode.

In this mode all alarms will be same from Monday to Thursday.

- Keypad is use for setting alarm.
- Press A for exit.
- Press B and C for next and previous alarm respectively.
- Press D for save alarm

Friday

Press 2 to Enter in this mode.

In this mode alarms are set for Friday only.

- Alarm setting procedure is same as mention previously.

One Day Only

Press 3 to Enter in this mode.

In this mode user can set alarm individually for any weekday.

- First select the weekday.

For example press 1 for Sunday, 2 for Monday………

- Alarm setting procedure is same as mention previously.

Important: Alarm setting format will be in 24 hours

DELETE ALL ALARMS:

Press 4 to Enter in Delete All Alarm Menu.

- Press 1 to Delete All Alarm
- Press 2 for Exit.

CHANGE PASSWORD

Press 5 to Enter in Change Password mode.

- First enter previous password and press D.
- Enter new password and press D for Save.
- Enter again new password for confirmation and press D.

Note: Password must be of 5 digits.

[Default Password: 12345]